

GPS Tracker Instructions

PLACE GPS TRACKER...

1. Inside the boat
2. As high as possible
3. LED lights up towards the sky

POWERING ON...

1. **Press the power button** 30 minutes before the start.
 2. Check that your boat is visible on GPS tracking webpage: www.sportrec.eu/events
- Switching off after finishing each day is not necessary.
If the tracker works and charges ok, you may keep it running from the start till the end of the regatta.

BATTERY MANAGEMENT

1. Let the tracker work on battery during races (~12h battery life).
 2. Charge the tracker between races or during the night.
- Some boats may be able to keep GPS power cable connected through the whole regatta. This depends on the power source. However, often the tracker will continue flashing LED lights, but will not work properly on the GPS webpage. In such case – disconnect the cable during races.

NORMAL OPERATION

- **GPS LED** is shining during race time. (It may be off between races).
- **GSM LED** is blinking slowly with 3 sec intervals.
- **POWER LED** is :
 - Dark = working on battery
 - Blinking = charging
 - Shining = fully charged



PROBLEMS & SOLUTIONS

- USB cable (not cigarette plug cable) is used to power the tracker >
 - **Disconnect USB-cable during race time** and charge during the night.
- **GSM LED** blinking fast (1 sec intervals) > **RESTART!** Disconnect cable, power off, power on.
- **POWER LED** is dark = not charging >
 - Move mini-USB plug inside the tracker very gently.
 - Let the tracker work on battery power.
Ask for a new charger for the next day.