

GPS Tracker Instructions

TRACKER PLACEMENT

- Inside the boat. Plug to cigarette power outlet (probably near navigator's table)
- As high above water line as possible
- **LED lights towards sky.** In case the tracker has to be vertical, place it number towards sky.

SWITCHING ON

- **Connect power cable and GPS tracker will switch on automatically.**
- Plug in the tracker at least 1 hour before the first start of the first day. Other days – 30 minutes before first start.
- If possible, please check the www.sportrec.eu/?page_id=24 that the tracker is visible online.

NORMAL OPERATION

- **GPS LED** is shining continuously.
- **PWR LED** is **blinking (charging)** or **shining continuously (fully charged)**.
GPS tracker has an internal battery that lasts about 12 hours (charging time is about 4 hours).
- **GSM LED** is blinking slowly with 2-3 sec intervals.



SOLUTIONS TO PROBLEMS

- **GPS LED** is blinking – looking for satellites.
- **GPS LED** is dark – in case of very low wind and calm sea, the movement sensor may put the tracker on standby. Just shake the tracker.
- **PWR LED** is dark (all lights are dark):
 - Check LED on the power cable that power cable is plugged in.
 - Move mini-USB plug inside the tracker very gently.
 - If these steps do not help, press power key 1 sec and let the tracker work from battery. Change the power cable before next day or charge the tracker via wall charger every night.
- **GSM LED is blinking fast** – connecting to mobile network failed (this is the most common issue).
 - Restart: disconnect power > press power key > wait till LEDs are off > connect power.

SWITCHING OFF

- If the boat battery has good capacity, there is no need to switch off the GPS tracker between race days.
- For switching off, **(1) disconnect the power and (2) press power off button.**
- After finishing on the last day, GPS tracker must be returned immediately.

SUPPORT

- GPS tracking links: www.sportrec.eu/?page_id=24. Support: Tõnis Erm, +372 56 669 977, tonis@sportrec.eu